

DEXIBELL

SOUND SET-UP

per S3 PRO, S7 PRO

"Sound Set-Up" è un file che può riconfigurare globalmente il tuo strumento caricando una delle liste dei suoni seguenti.

CLASSIC

PIANO
 Romantic
 Classic Grand
 German Classic
 VIVO Upright
 VIVO Grand
 VIVO Live
 German Grand
 German Live
 Bright Piano
 Piano Memory
 Pop Grand
 German Bright
 German Memory

E.PIANO

PERCUSSIVE
 Harpsi 8
 Harpsi 4
 Coupled Hps.
 Harpsi Lute
 Vibraphone
 Marimba
 Celesta
 Harp
 Tubular_Bells
 Xylophone
 Classic Percussion

ORGAN
 Principal
 Pincip&Flute
 Church
 Mixture

STRINGS
 Easy Strings
 FastOrchestra
 Attack Strings
 Choir Strings
 Large Strings
 MellowStrings
 Soft Strings
 Orchestra
 Pizzicato
 5th Strings
 Slow Analog
 Violin
 Viola

PAD/CHOIR
 Classic Choir
 Mmh Choir
 Space Vox

BRASS/SYNTH
 Full Brass
 Baroque Trump
 Classic Trumpet
 Trumpet Sect.
 Trumpet
 Trombone
 French_Horn
 Horns
 Flugelhorn
 Soprano Sax
 Tenor Sax
 Alto Sax

GUITAR/BASS
 Nylon Guitar

USER
 Bandoneon
 Clarinet
 Flute
 Oboe
 Piccolo
 Bassoon
 English_Horn
 Tuba

JAZZ_FUNK

PIANO
 VIVO Grand
 Japan Grand
 German Grand
 VIVO Live
 Japan Live
 German Live
 Pop Grand
 Japan Bright
 Classic Grand
 Japan Classic
 German Classic
 Bright Piano
 German Bright
 Piano Memory
 Japan Memory
 German Memory
 Elec.Grand
 E.Grand Trem
 Rock Piano

ORGAN
 Jazz Organ
 Blues Organ
 R&B Organ
 Gospel Organ
 Rock Organ
 Pop Organ
 Reggae Organ
 888888888
 888233211
 864200357
 686040000
 888604000

STRINGS
 Easy Strings
 FastOrchestra
 Attack Strings
 Choir Strings
 Large Strings
 MellowStrings
 Soft Strings
 Syn. Strings
 5th Strings
 Slow Analog
 Orchestra

PAD/CHOIR
 Warm Pad
 Soft Pad
 Square Pad
 Organ Pad
 Dark Pad
 Choir Pad
 Synth Vox
 Space Vox
 Fanta Bell

PERCUSSIVE
 Cool Clav
 Groovy Clav
 Doctor Clav
 Funky Clav
 Wah-Wah Clav
 Drive Clav
 Vibraphone
 Marimba
 Xylophone

E.PIANO
 Dyno Stage
 Suitcase
 Phaser EP
 Dyno Trem
 Dyno Bell
 Soft E.Piano
 Bright E.Piano
 FM Full Tines
 FM E.Piano
 Wurly
 Trem.Wurly

PIANO_E.PIANO_BASS

PIANO
 VIVO Upright
 VIVO Live
 Japan Grand
 German Grand
 Ragtime
 Honky Tonk
 Japan Live
 German Live
 VIVO Grand
 Pop Grand
 Japan Bright
 Classic Grand
 Japan Classic
 German Classic
 Bright Piano
 German Bright
 Piano Memory
 Japan Memory
 German Memory
 Elec.Grand
 E.Grand Trem
 Rock Piano

GUITAR/BASS
 Acoustic Bs.
 Double Bass
 Ac.Bass&Ride
 Double Bs&Ride
 Fingered Bs.
 5 String Bass
 Picked Bs.
 Modular Bass
 Fat Bass
 Reso Bass
 Big Reso Bass
 Sustain Bass
 Sustain Double Bs
 Smooth Bass

USER

E.PIANO
 Dyno Stage
 Dyno Trem
 Dyno Bell
 Suitcase
 Phaser EP
 Wurly
 Trem.Wurly
 Soft E.Piano
 Bright E.Piano
 FM Full Tines
 FM E.Piano
 Cool Clav
 Groovy Clav
 Doctor Clav
 Funky Clav
 Wah-Wah Clav
 Drive Clav

PERCUSSIVE

ORGAN

STRINGS

PAD/CHOIR

BRASS/SYNTH