

# DEXIBELL

## SOUND SET-UP

per SX7

"Sound Set-Up" è un file che può riconfigurare globalmente il tuo strumento caricando una delle liste dei suoni seguenti.

Alcuni suoni Factory verranno deselezionati e potranno essere istantaneamente ricaricati usando la funzione "Factory Sound" all'interno del Menu'.

CLASSIC		JAZZ_FUNK			PIANO_E.PIANO_BASS	
<b>PIANO</b>	<b>PAD/CHOIR</b>	<b>PIANO</b>	<b>STRINGS</b>	<b>GUITAR/BASS</b>	<b>PIANO</b>	<b>PERCUSSIVE</b>
Romantic	Classic Choir	German Grand	Orchestral_Strings	Double_Bass	Japan Grand	
Classic Grand	Mmh Choir	Japan Grand	Strings	DBass_&_Ride	German Grand	<b>ORGAN</b>
VIVO Grand	Space Vox	VIVO Grand	Slow Strings	Acoustic Bs.	VIVO Grand	
VIVO Live		Pop Grand	Orchestra	Ac.Bass&Ride	VIVO Live	<b>STRINGS</b>
German Grand	<b>BRASS/SYNTH</b>	VIVO Live	Fast Strings	Fingered Bs.	Pop Grand	
VIVO Upright	Full Brass	Classic Grand	Syn. Strings	5 String Bass	Classic Grand	<b>PAD/CHOIR</b>
	Baroque Trumpet	Elec.Grand	Strings Pad	Picked Bs.	VIVO Upright	
<b>E.PIANO</b>	Classic Trumpet	E.Grand Trem	80's Strings	Sustain Bass	Ragtime	<b>BRASS/SYNTH</b>
	Trumpet Sect.	Rock Piano	AnalogStrings	Sustain Double Bs	Honky Tonk	
	Trumpet	<b>E.PIANO</b>		Synth Bass	Elec.Grand	<b>GUITAR/BASS</b>
<b>PERCUSSIVE</b>	Trombone	Dyno Stage	<b>PAD/CHOIR</b>	Smooth Bass	E.Grand Trem	Acoustic Bs.
Harpsi 8'	French_Horn	Suitcase	Organ Pad	Fat Bass	Rock Piano	Ac.Bass&Ride
Harpsi 4'	Horns	Phaser EP	Dexi Heaven	Reso Bass		Double_Bass
Coupled Hps.	Flugelhorn	FM E.Piano	Fanta Bell	Big Reso Bs	<b>E.PIANO</b>	DBass_&_Ride
Harpsi Lute	Soprano Sax	FM Full Tines	Soft Pad	Modular_Bass	Dyno Stage	5 String Bass
Harp	Tenor Sax	Bright E.Piano	Warm Pad	Jazz Guitar	Suitcase	Fingered Bs.
Celesta	Alto Sax	Soft E.Piano	Square Pad	Nylon Guitar	Phaser EP	Picked Bs.
Marimba		Wurly	Dark Pad	Steel Guitar	Bright E.Piano	Sustain Bass
Vibraphone	<b>GUITAR/BASS</b>	Trem.Wurly	Space Vox	Overdrive GT.	Soft E.Piano	Sustain Double Bs
Xylophone	Nylon Guitar		Choir Pad	Muted_GT	FM E.Piano	Modular_Bass
		<b>PERCUSSIVE</b>	Synth Vox	Power_GT	FM Full Tines	FM_Bass
<b>ORGAN</b>	<b>USER</b>	Doctor Clav		<b>USER</b>	Doctor Clav	Smooth Bass
Principal	Bandoneon	Cool Clav	<b>BRASS/SYNTH</b>	Bandoneon	Cool Clav	Fat Bass
Pincip&Flute	Flute	Funky Clav	Full Brass	Harmonica	Funky Clav	Reso Bass
Church	Piccolo	Groovy Clav	Power Brass	Clarinet	Groovy Clav	Big Reso Bs
Mixture	Clarinet	Vibraphone	Trumpet Sect.		Wurly	
	Oboe	Xylophone	Trumpet		Trem.Wurly	<b>USER</b>
<b>STRINGS</b>	English_Horn	Marimba	Soprano Sax			
Orchestral_Strings	Bassoon		Tenor Sax			
Strings Ens.	Tuba	<b>ORGAN</b>	Alto Sax			
Strings	Tubular_Bells	Jazz Organ	Flugelhorn			
Slow Strings		Blues Organ	Horns			
Fast Strings		R&B Organ	Synth Brass			
Orchestra		Gospel Organ	Fat_Syn_Brass			
Violin		Rock Organ	Poly Brass			
Viola		Pop Organ	Lyle Lead			
		Reggae Organ	Fast Synth			
		8888888888	Super Saw			
		888233211				
		864200357				
		686040000				
		888604000				

**\*\* Dopo aver scaricato il file, creare una cartella chiamata "Setup" nella memoria USB (se non è già presente) e "decomprimere" il file scaricato in questa cartella.**