

H7/H3 Tone List

| Num. | Name | PC | CC00 |
|------|------|----|------|
|------|------|----|------|

MODERN

| | | | |
|------|--------------|---|---|
| 0001 | VIVO Grand | 2 | 0 |
| 0002 | Pop Grand | 2 | 1 |
| 0003 | VIVO Live | 2 | 2 |
| 0004 | Elec.Grand | 3 | 2 |
| 0005 | E.Grand Trem | 3 | 3 |
| 0006 | Rock Piano | 3 | 1 |
| 0007 | Honky Tonk | 4 | 1 |

CLASSIC

| | | | |
|------|---------------|---|---|
| 0008 | Classic Grand | 1 | 0 |
| 0009 | Romantic | 1 | 1 |
| 0010 | VIVO Upright | 1 | 2 |
| 0011 | Ragtime | 4 | 0 |
| 0012 | Harpsi 8' | 7 | 0 |
| 0013 | Harpsi 4' | 7 | 1 |
| 0014 | Coupled Hps. | 7 | 2 |
| 0015 | Pop Harpsi | 7 | 3 |

E.PIANO

| | | | |
|------|----------------|---|---|
| 0016 | Dyno Stage | 5 | 0 |
| 0017 | Suitcase | 5 | 1 |
| 0018 | Phaser EP | 5 | 2 |
| 0019 | Wurly | 5 | 5 |
| 0020 | Trem.Wurly | 5 | 6 |
| 0021 | Soft E.Piano | 5 | 3 |
| 0022 | Bright E.Piano | 5 | 4 |
| 0023 | FM Full Tines | 6 | 0 |
| 0024 | FM E.Piano | 6 | 1 |

ORGAN

| | | | |
|------|-----------------|----|---|
| 0025 | Principal | 20 | 0 |
| 0026 | Princip & Flute | 20 | 1 |
| 0027 | Church | 20 | 2 |
| 0028 | Mixture | 20 | 3 |
| 0029 | Pop Organ | 17 | 2 |
| 0030 | Jazz Organ | 18 | 0 |
| 0031 | Blues Organ | 18 | 1 |
| 0032 | Reggae Organ | 17 | 0 |
| 0033 | R&B Organ | 17 | 1 |
| 0034 | Rock Organ | 19 | 0 |
| 0035 | Gospel Organ | 19 | 1 |

ENSEMBLE

| | | | |
|------|--------------|----|---|
| 0036 | Slow Strings | 50 | 0 |
| 0037 | Strings | 50 | 1 |
| 0038 | Fast Strings | 49 | 0 |
| 0039 | Strings Ens. | 50 | 2 |
| 0040 | Orchestra | 49 | 1 |
| 0041 | Dark Strings | 50 | 3 |
| 0042 | Strings Pad | 51 | 0 |

| Num. | Name | PC | CC00 |
|------|------|----|------|
|------|------|----|------|

| | | | |
|------|---------------|----|---|
| 0043 | Syn. Strings | 51 | 1 |
| 0044 | 80's Strings | 52 | 0 |
| 0045 | Classic Choir | 53 | 1 |
| 0046 | Space Vox | 55 | 1 |
| 0047 | Mmh Choir | 53 | 0 |
| 0048 | Choir Pad | 54 | 1 |
| 0049 | Synth Vox | 55 | 0 |
| 0050 | Warm Pad | 90 | 0 |
| 0051 | Dark Pad | 54 | 0 |
| 0052 | Soft Pad | 90 | 1 |
| 0053 | Square Pad | 90 | 2 |
| 0054 | Brass Ens. | 62 | 1 |
| 0055 | Brass Sect. | 62 | 0 |
| 0056 | Synth Brass | 63 | 0 |
| 0057 | Poly Brass | 63 | 1 |
| 0058 | Poly Synth | 91 | 0 |
| 0059 | Super Saw | 91 | 1 |
| 0060 | Fast Synth | 91 | 2 |

(MORE)

| | | | |
|------|---------------|-----|---|
| 0061 | Vibraphone | 12 | 0 |
| 0062 | Xilophone | 14 | 0 |
| 0063 | Marimba | 13 | 0 |
| 0064 | Celesta | 9 | 0 |
| 0065 | Harp | 47 | 0 |
| 0066 | Cool Clav | 8 | 0 |
| 0067 | Groovy Clav | 8 | 1 |
| 0068 | Doctor Clav | 8 | 2 |
| 0069 | Funky Clav | 8 | 3 |
| 0070 | Nylon Guitar | 25 | 0 |
| 0071 | Steel Guitar | 26 | 0 |
| 0072 | Jazz Guitar | 27 | 0 |
| 0073 | Overdrive GT. | 30 | 0 |
| 0074 | Fanta Bell | 101 | 0 |
| 0075 | Dexi Heaven | 101 | 1 |
| 0076 | Acoustic Bs. | 33 | 0 |
| 0077 | Fingered Bs. | 34 | 0 |
| 0078 | Picked Bs. | 35 | 0 |
| 0079 | Ac.Bass&Ride | 33 | 1 |
| 0080 | Synth Bass | 39 | 0 |