

DEXIBELL

SOUND SET-UP

per J7

"Sound Set-Up" è un file che può riconfigurare globalmente il tuo strumento caricando una delle liste dei suoni seguenti.

Alcuni suoni Factory verranno deselezionati e potranno essere istantaneamente ricaricati usando la funzione "Factory Sound" all'interno del Menu'.

CLASSIC		JAZZ_FUNK			PIANO_E.PIANO_BASS	
PIANO	SYNTH/OTHER	PIANO	BRASS/ENSEMBLE	SYNTH/OTHER	PIANO	BRASS/ENSEMBLE
Romantic	Violin	German Grand	Full Brass	Lyle Lead	German Grand	
Classic Grand	Viola	Japan Grand	Synth Brass	Super Saw	Japan Grand	SYNTH/OTHER
VIVO Grand	Flute	VIVO Grand	Poly Brass	Fast Synth	VIVO Grand	Pedal Bass
VIVO Live	Piccolo	Pop Grand	Fat Syn Brass	Fanta Bell	Pop Grand	Pedal DoubleBs
German Grand	Clarinet	VIVO Live	Slow Strings	Dexi Heaven	VIVO Live	Acoustic Bs.
VIVO Upright	Oboe	Classic Grand	Strings	Soprano Sax	VIVO Upright	Double Bass
Harpsi 8'	English_Horn	Elec.Grand	Fast Strings	Alto Sax	Classic Grand	Ac.Bass&Ride
Harpsi 4'	Bassoon	E.Grand Trem	Orchestral Strings	Tenor Sax	Ragtime	Double Bs&Ride
Coupled Hps.	Harp	Rock Piano	Orchestra	Trumpet	Elec.Grand	Fingered Bs.
Harpsi Lute	Nylon Guitar	Vibraphone	Syn. Strings	Classic Trumpet	E.Grand Trem	5 String Bass
Vibraphone		Xylophone	80's Strings	Trumpet Sect.	Rock Piano	Picked Bs.
Celesta	USER	Marimba	AnalogStrings	Flugelhorn		Smooth Bass
Marimba			Warm Pad	Horns		Synth Bass
		E.PIANO	Soft Pad	Nylon Guitar	E.PIANO	Modular Bass
E.PIANO		Dyno Stage	Square Pad	Steel Guitar	Dyno Stage	Fat Bass
		Suitcase	Organ Pad	Jazz Guitar	Suitcase	Reso Bass
BRASS/ENSEMBLE		Phaser EP	Dark Pad	Overdrive GT.	Phaser EP	Big Reso Bass
Orchestral Strings		Wurly	Choir Pad	Acoustic Bs.	Bright E.Piano	FM Bass
Slow Strings		Trem.Wurly	Synth Vox	Double Bass	Soft E.Piano	
Strings		Soft E.Piano	Space Vox	Ac.Bass&Ride	FM Full Tines	USER
Orchestra		Bright E.Piano		Double Bs&Ride	FM E.Piano	
Full Brass		FM Full Tines		Fingered Bs.	Wurly	
Trumpet Sect.		FM E.Piano		5 String Bass	Trem.Wurly	
Classic Trumpet		Cool Clav		Picked Bs.	Cool Clav	
Baroque Trump		Groovy Clav		Smooth Bass	Groovy Clav	
Trumpet		Doctor Clav		Synth Bass	Doctor Clav	
Trombone		Funky Clav		Pedal Bass	Funky Clav	
Horns				Pedal DoubleBs		
French_Horn				Modular Bass		
Flugelhorn				Fat Bass		
Soprano Sax				Reso Bass		
Alto Sax				Big Reso Bass		
Tenor Sax				FM Bass		
Tuba						
Classic Choir				USER		
Space Vox						

**** Dopo aver scaricato il file, creare una cartella chiamata "Setup" nella memoria USB (se non è già presente) e "decomprimere" il file scaricato in questa cartella.**