

# DEXIBELL

## SOUND SET-UP

per S9

"Sound Set-Up" è un file che può riconfigurare globalmente il tuo strumento caricando una delle liste dei suoni seguenti.

Alcuni suoni Factory verranno deselezionati e potranno essere istantaneamente ricaricati usando la funzione "Factory Sound" all'interno del Menu'.

CLASSIC		JAZZ_FUNK			PIANO_E.PIANO_BASS	
<b>PIANO</b>	<b>PAD/CHOIR</b>	<b>PIANO</b>	<b>STRINGS</b>	<b>GUITAR/BASS</b>	<b>PIANO</b>	<b>STRINGS</b>
Romantic	Classic Choir	German Grand	Easy Strings	Jazz Guitar	German Grand	
Classic Grand	Mmh Choir	Japan Grand	FastOrchestra	Nylon Guitar	Japan Grand	<b>PAD/CHOIR</b>
VIVO Grand	Space Vox	VIVO Live	Attack Strings	Steel Guitar	VIVO Live	<b>BRASS/SYNTH</b>
VIVO Live		VIVO Grand	Choir Strings	Overdrive GT.	VIVO Upright	
German Grand	<b>BRASS/SYNTH</b>	Pop Grand	Large Strings	Muted_GT	VIVO Grand	
VIVO Upright	Full Brass	Classic Grand	Mellow strings	Power_GT	Pop Grand	<b>GUITAR/BASS</b>
	Baroque Trump	Bright Piano	Soft Strings	Acoustic Bs.	Classic Grand	Acoustic Bs.
<b>E.PIANO</b>	Classic Trumpet	Piano Memory	5th Strings	Double_Bass	Bright Piano	Double_Bass
	Trumpet Sect.	Elec.Grand	Slow Analog	Ac.Bass&Ride	Piano Memory	Ac.Bass&Ride
<b>PERCUSSIVE</b>	Trumpet	E.Grand Trem		DBass_&_Ride	Ragtime	DBass_&_Ride
Harpsi 8'	Trombone	Rock Piano	<b>PAD/CHOIR</b>	Fingered Bs.	Elec.Grand	Fingered Bs.
Harpsi 4'	French_Horn		Warm Pad	5 String Bass	E.Grand Trem	5 String Bass
Coupled Hps.	Horns	<b>E.PIANO</b>	Soft Pad	Picked Bs.	Rock Piano	Picked Bs.
Harpsi Lute	Flugelhorn	Dyno Stage	Square Pad	Sustain Bass		Sustain Bass
Harp	Soprano Sax	Dyno Trem	Organ Pad	Sustain Double Bs	<b>E.PIANO</b>	Sustain Double Bs
Celesta	Tenor Sax	Dyno Bell	Choir Pad	Modular_Bass	Dyno Stage	Modular_Bass
Marimba	Alto Sax	Suitcase	Space Vox	Fat Bass	Dyno Trem	Fat Bass
Vibraphone		Phaser EP	Fanta Bell	Reso Bass	Dyno Bell	Reso Bass
Classic Percussion	<b>GUITAR/BASS</b>	Wurly	Dark Pad	Big Reso Bs	Suitcase	Big Reso Bs
		Trem.Wurly		Synth Bass	Phaser EP	Smooth Bass
<b>STRINGS</b>	<b>USER</b>	Soft E.Piano	<b>BRASS/SYNTH</b>	Smooth Bass	Wurly	
Orchestral_Strings	Bandoneon	Bright E.Piano	Full Brass		Trem.Wurly	<b>USER</b>
Fast Strings	Flute	FM Full Tines	Power Brass	<b>USER</b>	Soft E.Piano	Soft E.Piano
Slow Strings	Piccolo	FM E.Piano	Trumpet Sect.	Bandoneon	Bright E.Piano	Bright E.Piano
Violin	Clarinet		Trumpet	Harmonica	FM Full Tines	FM Full Tines
Viola	Oboe	<b>PERCUSSIVE</b>	Soprano Sax	Clarinet	FM E.Piano	FM E.Piano
	English_Horn	Doctor Clav	Tenor Sax	Flute		
	Bassoon	Cool Clav	Alto Sax		<b>PERCUSSIVE</b>	Doctor Clav
	Tuba	Funky Clav	Flugelhorn		Doctor Clav	Cool Clav
		Groovy Clav	Horns		Funky Clav	Funky Clav
		Wah-Wah Clav	Synth Brass		Groovy Clav	Groovy Clav
		Drive Clav	Poly Brass		Wah-Wah Clav	Wah-Wah Clav
		Vibraphone	Fat_Syn_Brass		Drive Clav	Drive Clav
		Marimba	Lyle Lead			
		Xylophone	Super Saw			
			Fast Synth			
			Dexi Heaven			