

H5 Tone List

Num.	Name	PC	CC00
------	------	----	------

MODERN

0001	VIVO Grand	2	0
0002	Pop Grand	2	1
0003	VIVO Live	2	2
0004	Elec. Grand	3	2
0005	E. Grand Trem	3	3
0006	Rock Piano	3	1
0007	Honky Tonk	4	1

CLASSIC

0008	Classic Grand	1	0
0009	Romantic	1	1
0010	VIVO Upright	1	2
0011	Ragtime	4	0
0012	Harpsi 8'	7	0
0013	Harpsi 4'	7	1
0014	Coupled Hps.	7	2
0015	Pop Harpsi	7	3

E.PIANO

0016	Dyno Stage	5	0
0017	Suitcase	5	1
0018	Phaser EP	5	2
0019	Wurly	5	5
0020	Trem. Wurly	5	6
0021	Soft E. Piano	5	3
0022	Bright E. Piano	5	4
0023	FM Full Tines	6	0
0024	FM E. Piano	6	1

ORGAN

0025	Principal	20	0
0026	Princip & Flute	20	1
0027	Church	20	2
0028	Mixture	20	3
0029	Pop Organ	17	2
0030	Jazz Organ	18	0
0031	Blues Organ	18	1
0032	Reggae Organ	17	0
0033	R&B Organ	17	1
0034	Rock Organ	19	0
0035	Gospel Organ	19	1

ENSEMBLE

0036	Slow Strings	50	0
0037	Strings	50	1
0038	Fast Strings	49	0
0039	Strings Ens.	50	2
0040	Orchestra	49	1
0041	Dark Strings	50	3
0042	Strings Pad	51	0

Num.	Name	PC	CC00
------	------	----	------

0043	Syn. Strings	51	1
0044	80's Strings	52	0
0045	Classic Choir	53	1
0046	Space Vox	55	1
0047	Mmh Choir	53	0
0048	Choir Pad	54	1
0049	Synth Vox	55	0
0050	Warm Pad	90	0
0051	Dark Pad	54	0
0052	Soft Pad	90	1
0053	Square Pad	90	2
0054	Brass Ens.	62	1
0055	Brass Sect.	62	0
0056	Synth Brass	63	0
0057	Poly Brass	63	1
0058	Poly Synth	91	0
0059	Super Saw	91	1
0060	Fast Synth	91	2

(MORE)

0061	Vibraphone	12	0
0062	Xilophone	14	0
0063	Marimba	13	0
0064	Celesta	9	0
0065	Harp	47	0
0066	Cool Clav	8	0
0067	Groovy Clav	8	1
0068	Doctor Clav	8	2
0069	Funky Clav	8	3
0070	Nylon Guitar	25	0
0071	Steel Guitar	26	0
0072	Jazz Guitar	27	0
0073	Overdrive GT.	30	0
0074	Fanta Bell	101	0
0075	Dexi Heaven	101	1
0076	Acoustic Bs.	33	0
0077	Fingered Bs.	34	0
0078	Picked Bs.	35	0
0079	Ac. Bass & Ride	33	1
0080	Synth Bass	39	0