

VIVOP7/P3 Tone List

Num.	Name	PC	CC00
------	------	----	------

PIANO

0001	VIVO Grand	2	0
0002	Pop Grand	2	1
0003	VIVO Live	2	2
0004	VIVO Upright	1	2
0005	Elec.Grand	3	2
0006	Rock Piano	3	1
0007	Ragtime	4	0
0008	Honky Tonk	4	1

E.PIANO

0009	Dyno Stage	5	0
0010	Suitcase	5	1
0011	Wurly	5	5
0012	Trem.Wurly	5	6
0013	Soft E.Piano	5	3
0014	Bright E.Piano	5	4
0015	FM Full Tines	6	0

PLUCKED/PERCUSSIVE

0016	Cool Clav	8	0
0017	Groovy Clav	8	1
0018	Funky Clav	8	3
0019	Vibraphone	12	0
0020	Xylophone	14	0
0021	Marimba	13	0
0022	Harpsi 8'	7	0

ORGAN

0023	Jazz Organ	18	0
0024	Blues Organ	18	1
0025	Reggae Organ	17	0
0026	Rock Organ	19	0
0027	Principal	20	0
0028	Church	20	2
0029	Mixture	20	3

ENSEMBLE

0030	Slow Strings	50	0
0031	Strings	50	1
0032	Warm Pad	90	0
0033	Classic Choir	53	1
0034	Space Vox	55	1
0035	Brass Sect.	62	0
0036	Synth Brass	63	0

GUITAR/BASS

0037	Nylon Guitar	25	0
0038	Steel Guitar	26	0
0039	Jazz Guitar	27	0
0040	Acoustic Bs.	33	0

Num.	Name	PC	CC00
------	------	----	------

0041	Fingered Bs.	34	0
0042	Picked Bs.	35	0
0043	Synth Bass	39	0

USER

0044	Romantic	1	1
0045	Classic Grand	1	0
0046	Celesta	9	0
0047	Harp	47	0
0048	E.Grand Trem	3	0
0049	Phaser EP	5	2
0050	FM E.Piano	6	1
0051	Doctor Clav	8	2
0052	Harpsi 4'	7	1
0053	Coupled Hps.	7	2
0054	Pop Harpsi	7	3
0055	Pop Organ	17	2
0056	R&B Organ	17	1
0057	Gospel Organ	19	1
0058	Princip& Flute	20	1
0059	Fast Strings	49	0
0060	Strings Ens.	50	2
0061	Orchestra	49	1
0062	Dark Strings	50	3
0063	Strings Pad	51	0
0064	Syn. Strings	51	1
0065	80's Strings	52	0
0066	Soft Pad	90	1
0067	Square Pad	90	2
0068	Dark Pad	54	0
0069	Mmh Choir	53	0
0070	Choir Pad	54	1
0071	Synth Vox	55	0
0072	Brass Ens.	62	1
0073	Poly Brass	63	1
0074	Fanta Bell	101	0
0075	Dexi Heaven	101	1
0076	Poly Synth	91	0
0077	Super Saw	91	1
0078	Fast Synth	91	2
0079	Overdrive GT.	30	0
0080	Ac.Bass& Ride	33	1