

VIVOS7/S3 Tone List

Num.	Name	PC	CC00
PIANO			
0001	VIVO Grand	2	0
0002	Pop Grand	2	1
0003	VIVO Live	2	2
0004	Classic Grand	1	0
0005	VIVO Upright	1	2
0006	Elec.Grand	3	2
0007	E.Grand Trem	3	3
0008	Rock Piano	3	1
0009	Ragtime	4	0
0010	Honky Tonk	4	1
E.PIANO			
0011	Dyno Stage	5	0
0012	Suitcase	5	1
0013	Phaser EP	5	2
0014	Wurly	5	5
0015	Trem.Wurly	5	6
0016	Soft E.Piano	5	3
0017	Bright E.Piano	5	4
0018	FM Full Tines	6	0
0019	FM E.Piano	6	1
PLUCKED/PERCUSSIVE			
0020	Cool Clav	8	0
0021	Groovy Clav	8	1
0022	Doctor Clav	8	2
0023	Funky Clav	8	3
0024	Vibraphone	12	0
0025	Xylophone	14	0
0026	Marimba	13	0
0027	Harpsi 8'	7	0
0028	Pop Harpsi	7	3
ORGAN			
0029	Jazz Organ	18	0
0030	Blues Organ	18	1
0031	Reggae Organ	17	0
0032	R&B Organ	17	1
0033	Rock Organ	19	0
0034	Gospel Organ	19	1
0035	Principal	20	0
0036	Church	20	2
0037	Mixture	20	3
STRINGS			
0038	Slow Strings	50	0
0039	Strings	50	1
0040	Fast Strings	49	0
0041	Strings Ens.	50	2

Num.	Name	PC	CC00
0042	Orchestra	49	1
0043	Dark Strings	50	3
0044	StringsPad	51	0
0045	Syn.Strings	51	1
0046	80's Strings	52	0
PAD/CHOIR			
0047	Warm Pad	90	0
0048	Soft Pad	90	1
0049	Square Pad	90	2
0050	Mmh Choir	53	0
0051	Dark Pad	54	0
0052	Classic Choir	53	1
0053	Choir Pad	54	1
0054	Synth Vox	55	0
0055	Space Vox	55	1
BRASS/SYNTH			
0056	Brass Sect.	62	0
0057	Brass Ens.	62	1
0058	Synth Brass	63	0
0059	Poly Brass	63	1
0060	Fanta Bell	101	0
0061	Dexi Heaven	101	1
0062	Poly Synth	91	0
0063	Super Saw	91	1
0064	Fast Synth	91	2
GUITAR/BASS			
0065	Nylon Guitar	25	0
0066	Steel Guitar	26	0
0067	Jazz Guitar	27	0
0068	Overdrive GT.	30	0
0069	Acoustic Bs.	33	0
0070	Fingered Bs.	34	0
0071	Picked Bs.	35	0
0072	Ac.Bass&Ride	33	1
0073	Synth Bass	39	0
USER			
0074	Romantic	1	1
0075	Harpsi 4'	7	1
0076	Coupled Hps.	7	2
0077	Princip&Flute	20	1
0078	Pop Organ	17	2
0079	Celesta	9	0
0080	Harp	47	0