

DEXIBELL

VIVO OS 04.16

Additional features compared to the previous version

1) USB Audio works also with WINDOWS

USB Computer Port can send/receive digital AUDIO IN/OUT simultaneously with MIDI in all computers equipped with WINDOWS.

(MAC OSX and LINUX already worked in the previous software version).

Using the instrument with your Computer

If you use a A → B type USB cable (commercially available) to connect the USB COMPUTER port of your instrument to your computer's USB connector, you can record and play audio or/and MIDI data by your MIDI software (DAW software).

The instrument can transmit/receive audio streaming at 24 bit 48 Khz.

2) Delay Time up to 1000ms

On all DELAY effects, the time value of Delay R, Delay L, Delay C parameters has been increased up to 1000ms.

3) "USA Rev PLT" and "Italian Rev PLT" has been added to the internal tone list

4) Several bugs fixed

DEXIBELL

VIVO OS 04.15

- Several bugs fixed

DEXIBELL

VIVO OS 04.14

- Several bugs fixed

DEXIBELL

VIVO OS 04.13

- Several bugs fixed

DEXIBELL

VIVO OS 04.12

- **USB audio on RECORDER**
Added ability to record USB audio input on RECORDER
- **USB audio levels can be saved as GLOBAL parameters**
USB Audio Input / Output levels can be saved as GLOBAL parameters.
- **Several bugs fixed**



DEXIBELL

VIVO OS 04.11

- New SOUND LIST REORDER function

Press MENU/EXIT button and select SOUND LIST using DATA ENTRY, UP/DOWN  buttons, then press RIGHT  button.





Select the Sound you need to reorder using the DATA ENTRY or UP/DOWN  buttons, by pressing the LEFT/RIGHT  buttons or by pressing the Sound Family buttons. You can listen the selected sound.




Press MOVE function button



Select the new position where you want to put the sound using the DATA ENTRY or UP/DOWN  buttons and LEFT/RIGHT  button.



Press OK function button to confirm or press CANCEL function button to cancel.







Press MENU/EXIT button to exit from SOUND LIST ambient.

Note:


Make EXPORT SOUND SETUP or BACKUP if you want to save your sound list order.


Make a FACTORY SOUND if you want to go back to the original sound list order.


- New MEMORY LIST REORDER function

Press MENU/EXIT button, select MEMORY using DATA ENTRY or UP/DOWN  buttons, then press RIGHT  button. Select REORDER using DATA ENTRY or UP/DOWN  buttons, then press RIGHT  button.



Select the Memory you need to reorder using the DATA ENTRY or UP/DOWN  button and press MOVE function button (the selected memory is also recalled).



Select the new position where you want to put the selected memory using the DATA ENTRY or UP/DOWN  buttons.



Press OK function button to confirm or press CANCEL function button to cancel.



Press MENU/EXIT button to exit from MEMORY ambient.

Note:

Make EXPORT MEMORY SET or BACKUP if you want to save your new memory list.
Make a FACTORY RESET if you want to go back to the original Memory list.

- **Added PANIC function**
“All notes off” and “Reset All Controllers” messages can be now sent internally and via MIDI inside Menu
- **In MASTER SONG ambient, the selection of NEXT SONG and PREVIOUS SONG using LEFT/RIGHT buttons on panel, have been added.**
From MASTER SONG ambient it is possible to select songs contained into a USB memory.
- **Sympathetic resonances**
The Sympathetic resonance algorithm has been significantly improved, during the repetition of the single notes.
- **Several bugs adjustment**